



Hospita


Design + Engineering GROHE Germany

95.219.231/ÄM 227495/06.13










Please pass these instructions on to the end user of the fitting.

ı





Application

Can be used in conjunction with: Pressurised storage heaters, thermally and hydraulically controlled instantaneous heaters. Operation with low-pressure displacement water heaters is **not** possible.

Specifications

Minimum flow pressure	0.1 bar
 Maximum operating pressure 	10 bar
Test pressure	16 bar

If static pressure is greater than 5 bar, fit pressure reducer.

•	Flow rate at 3 bar flow pressure:	
	20 025 with mousseur 13 929:	approx. 12 l/min
	30 978 with mousseur 13 955:	approx. 7 l/min
	20 427 with mousseur 64 450:	approx. 5,8 l/min

Flow rate at 0,1 bar flow pressure:
 20 025 with mousseur 13 905: approx. 5 l/min
 30 978 with mousseur 13 905: approx. 5 l/min

Temperature (20 427)

 Hot water inlet (maximum):
 Recommended (energy saving):

 Water connection
 80 °C
 60 °C
 Water connection

hot - left

Installation

Flush piping system prior and after installation of fitting thoroughly (Consider EN 806)!

For mounting pillar tap 20 025 or 30 978 see fold-out page III, Fig. [1] and [2].

For mounting pillar tap 20 427 see fold-out page III, Fig. [1] and [3].

Refer to the dimensional drawings on fold-out page I.

The cold water supply must be connected on the right and the hot water supply on the left.

Open cold- and/or hot water supply and check connections for watertightness!

Check fitting for correct function.

Maintenance

Inspect and clean all parts, replace if necessary and grease with special grease.

Shut off cold and/or hot water supply!

Ceramic headpart (A), see fold-out page III, Fig. [4].

- 1. Pull off handle (B).
- 2. Unscrew screw (C) and pull off snap inserts (D).
- 3. Unscrew ceramic headpart (A) using a 17mm wrench.
- 4. Change complete ceramic headpart (A) or o-ring (A1).

Observe the different replacement part numbers of the ceramic headparts.

Assemble in reverse order.

Replacement parts, see fold-out page III, Fig. [5] and fold-out page II (* = special accessories).


Care


Dear Customer,


We want to ensure that you get long-lasting satisfaction and pleasure from your GROHE fitting. Therefore, please read the following care instructions because damage to the surface and underlying material resulting from improper treatment is not covered by warranty.


Do not use any abrasive sponges or scouring agents for cleaning. We also advise you not to use cleaning agents containing solvent or acid, limescale removers, household vinegar and cleaning agents with acetic acid in them. They are aggressive to the surface - and will leave your fitting dull and scratched. As the formulations of commercially available cleaning agents frequently change, we cannot guarantee they will provide the gentle care our fitting deserves.


Clean the fitting with a little soap and a moist cloth only, then simply rinse off and wipe dry. You can avoid lime spots by drying the fitting each time it is used. If lime deposits do occur, remove them with **GrohClean**, our environment-friendly cleaning liquid. **GrohClean** is specially formulated to clean the surface of our fittings gently. **GrohClean** is available from your supplier.











(D)

© +49 571 3989 333 impressum@grohe.de

A

(£) +43 1 68060 info-at@grohe.com

AUS

Argent Sydney
(C) +(02) 8394 5800
Argent Melbourne
(C) +(03) 9682 1231



(£) +32 16 230660 info.be@grohe.com

(BG)

(+359 2 9719959 grohe-bulgaria@grohe.com

CAU

(C) +99 412 497 09 74 info-az@grohe.com

CDN

(£) +1 888 6447643 info@grohe.ca

(CH)

(£) +41 448777300 info@grohe.ch

CN

(C) +86 21 63758878

(CY)

(C) +357 22 465200 info@grome.com

(CZ)

© +420 22509 1082 grohe-cz@grohe.com

DK)

(£) +45 44 656800 grohe@grohe.dk

(E

(C) +34 93 3368850 grohe@grohe.es

EST

(£) +372 6616354 grohe@grohe.ee

F

(C) +33 1 49972900 marketing-fr@grohe.com (FIN)

(C) +358 10 8201100 teknocalor@teknocalor.fi

GB

(C) +44 871 200 3414 info-uk@grohe.com

(GR)

(*) +30 210 2712908 nsapountzis@ath.forthnet.gr

(H)

(C) +36 1 2388045 info-hu@grohe.com

(HK)

(£) +852 2969 7067 info@grohe.hk

() +39 2 959401 info-it@grohe.com

(ND)

(+91 124 4933000 customercare.in@grohe.com

IS

(C) +354 515 4000 jonst@byko.is

J

(C) +81 3 32989730 info@grohe.co.jp

KZ

(c) +7 727 311 07 39 info-cac@grohe.com

(LT)

(C) +372 6616354 grohe@grohe.ee

(LV)

(C) +372 6616354 grohe@grohe.ee

MAL

(+1 800 80 6570 info-singapore@grohe.com

 $\overline{\mathsf{N}}$

(£) +47 22 072070 grohe@grohe.no

NL

() +31 79 3680133 vragen-nl@grohe.com (NZ)

() +09/373 4324

(P)

(+351 234 529620 commercial-pt@grohe.com

(PL)

(C) +48 22 5432640 biuro@grohe.com.pl

RI

(C) +62 21 2358 4751 info-singapore@grohe.com

(RO)

(£) +40 21 2125050 info-ro@grohe.com

ROK

**E 2 559 0790 info-singapore@grohe.com

(RP)

(C) +63 2 8041617

RUS

(C) +7 495 9819510 info@grohe.ru

S

© +46 771 141314 grohe@grohe.se

SGP

(+65 6 7385585 info-singapore@grohe.com

(SK)

(£) +420 22509 1082 grohe-cz@grohe.com

T

**E66 2610 3685 info-singapore@grohe.com

(TR)

(+90 216 441 23 70 GroheTurkey@grome.com

(UA)

(£) +38 44 5375273 info-ua@grohe.com

USA

(+1 800 4447643 us-customerservice@grohe.com

VN

(+84 8 5413 6840 info-singapore@grohe.com



Eastern Mediterranean, Middle East - Africa Area Sales Office: (*) +357 22 465200 info@grome.com

(R) (M) (UAE) YEM) (P) +971 4 3318070

grohedubai@grome.com

Far East Area Sales Office: (*) +65 6311 3600 info@grohe.com.sg

